

## **NORDIC COMPONENTS TACTICAL COMPENSATOR**

-On pre-threaded barrels, such as an AR15, this compensator can be installed by removing the existing muzzle device and installing the supplied crush washer and compensator.

-Degrease the threads on the barrel and the compensator prior to installation.

-The included crush washer allows you to 'clock' or time the brake properly. 4 – 1/8" holes on the compensator are to be positioned up, and the large 7/16" hole is to be positioned left to right.

-A 7/16" dia. rod may be used to time the compensator in place. We recommend the use of a barrel vise to secure the barrel